




Montageanleitung
Assembly Instructions
Instructions de montage
Istruzione di montaggio
Монтажная инструкция
(электрическая модель)























Achtung:
Bitte das beigefügte Instruktionsblatt der **IRVAR** Elektro-Heizpatrone beachten.

Attention:
Please observe the installation instructions of the immersion heater type **IRVAR** supplied with this unit.




Attention:
Veuillez svp. observer la fiche d'instruction de la résistance électrique **IRVAR**.

Attenzione:
Vedasi istruzione di servizio per resistenza elettrica **IRVAR**.

Внимание!
Пожалуйста, обратите внимание на прилагаемую инструкцию для погружного электронагревательного элемента **IRVAR**.



Montageanleitung
Assembly Instructions
Instructions de montage
Istruzione di montaggio
Монтажная инструкция
(водяная или
комбинированная
модель)



*узел подключения
(заказывается дополнительно)

Achtung:

Wird der Design-Heizkörper zusätzlich mit einer **IRVAR** Elektro-Heizpatrone ausgerüstet, ist das beigefügte Instruktionsblatt der **IRVAR** Elektro-Heizpatrone zu beachten.

Attention:

If this towel radiator is to be installed with an immersion heater type **IRVAR**, then please observe the installation instructions supplied with the immersion heater.

Attention:

Si le radiateur est équipé d'une résistance électrique **IRVAR**, la fiche d'instruction en annexe est à observer.

Attenzione:

Sé lo scaldasalviette sarà fornito di resistenza elettrica **IRVAR**, vedasi in allegato istruzione di servizio.

Внимание!

Если радиатор дополнительно оснащен погружным электронагревательным элементом **IRVAR**, обратите внимание на прилагаемую инструкцию для погружного электронагревательного элемента **IRVAR**.

